



SECTION 6. EXPLODED VIEW

6.1 BASE



LEVEL	NO	NEW P/N	OLD P/N	DESCRIPTION
1		ABCY0010601	51014155	BASE ASSY
. 2	1	MHHC0010801	24612408	HOUSING, UPPER
. 2	2	MBJC0004601	24612406	BUTTON, FUNCTION
. 2	3	MCCZ0001001	24612407	CAP
. 2	4	MLDY0001801	24612409	LIGHT PIPE
. 2	5	MSDD0002301	22611302	SPRING, PLATE
...3	6	SNCB0003101	22511269	ANTENNA, CT, BASE SET
. . . 3		SAFA0010001	31313124	PCB ASSY, MAIN, AUTO
. . . 4	7	SPFY0015501	27211937	PCB, MAIN
. . . 4	8	SMRB0001201	25211209	RF MODULE, BASE SET
...3	9	SNCB0003001	22511270	ANTENNA, CT, BASE SET
. 2	10	MHHA0005501	24612402	HOUSING, LOWER

6.2 HANDSET



LEVEL	NO	NEW P/N	OLD P/N	DESCRIPTION
1		AHAA0001501	51014157	HANDSET ASSY, CT
. 2	1	MHDA0003301	24612405	HANDSET, UPPER
. 2	2	MSDD0001701	22611305	SPRING, PLATE LEFT
. 2		MSDD0001801	22611304	SPRING, PLATE RIGHT
. . 3		SAEY0008001	41313123	PCB ASSY, KEYPAD
. . 3	3	SUMY0003101	26711176	MICROPHONE
. . 3	8	SAEA0003501	31313122	PCB ASSY, KEYPAD, AUTO
. . . 4	10	SMRH0001001	25211208	RF MODULE, HANDSET
. . . 4		SPEY0006101	27211936	PCB, KEYPAD
. . 3		SURY0003401	26711174	RECEIVER
. 2	4	MWAC0007201	24512181	WINDOW, LCD
. 2	5	MBHY0002601	24711825	BUMPER
. 2	6	MKAA0002801	24711827	KEYPAD, DIAL
. 2	7	MHGD0000601	24612403	HOLDER, LCD
. 2	9	MSDD0001901	22611303	SPRING, PLATE A
. 2		MSDD0002001	22611300	SPRING, PLATE B
. 2		MSDD0002101	22611299	SPRING, PLATE C
. 2		MSDD0002201	22611301	SPRING, PLATE D
. . 3	11	SNCH0002601	22511268	ANTENNA, CT, HANDSET
. 2	12	MHDB0003701	24612404	HANDSET, LOWER
. 2	13	MCJA0002401	24612410	COVER, BATTERY